


## ROTOR – MCI (Touchscreen) - Connections

### Introduction

This document shows the necessary connections for the MCI (touchscreen) computer on a ROTOR.

### Example connection

**Please Note:** The network connector may switch to the one next to it as it depends on the way the MCI has been set up. The easiest way to check this is if the network connection is live the lights at the connection will flash.



### Summary

If more explanation is required do not hesitate to contact the Singer Instruments Technicians via [technicalsupport@singerinstruments.com](mailto:technicalsupport@singerinstruments.com)